

### Preparation

**1**

Display warning signs.

**2**

Check equipment, especially plug and cable. Report any fault or damage to a supervisor. Label as faulty and do not use.

**3**

If spray burnishing fill dosing bottle with required solution.

**4**

Dust control floor area with mop sweeper.

### Operation

**5**

Do not plug in and switch on at socket until machine is ready for use.

**6**

Tip machine back to put handle on floor and fit pad. Turn pad retainer anticlockwise to lock on.

**7**

Hold cable over handle, NOT over shoulder.

**8**

Keep cable flat on the floor, NOT taut.

### Straight Line Burnishing

**9**

Where possible, start at side nearest plug socket.

**10**

Turn away from the socket at the end of each pass so cable lies on the area already cleaned. Allow 2" overlap.

### Spray Burnishing

**11**

Press dosing button briefly once every 5 – 10 paces (depending on soiling). Avoid over wetting pad. Cover whole area.

**12**

Check pad/brush regularly for clogging. Unplug and turn/change as required.

**13**

Change to fresh, dry pad and repeat procedure – buffing only.

**14**

Put handle in upright position when not in use. Unplug if left unsupervised.

**15**

When changing socket, coil cable from machine to plug, not plug to machine, to avoid twisting.

**16**

Unplug.

**17**

Wind cable back into handle, wiping clean with a damp cloth as you do.

**18**

Wipe machine clean with a damp cloth.

### Maintenance

**19**

Empty dosing bottle and rinse bottle and pipe with warm water.

**20**

Do not store machine with pad fitted.

