

TASKI vacuums quick guide to

cleaning and disinfection*

for control of SARS-CoV-2 which causes COVID-19



Product guide

Oxivir® wipes (AHP® based product)





Oxivir Excel / Sporicide Wipes

Oxivir 1 / Tb Wipes

To clean and disinfect all surfaces

Oxivir, ready-to-use (AHP based product)



Oxivir Plus /



Excel

To clean and disinfect all surfaces

TASKISUM disposable cloth



Single-use cloths to ease disinfection of all surfaces

Disinfection before use

Always before using the machine



Wear gloves when disinfecting the main touch points with chosen product



Follow chemical instructions (Do not spray directly on the vacuum)



Vacuum exterior

Ensure full coverage with attention to touch points



On / off button and cable

Ensure full coverage with attention to touch points



Hose, elbow, tube and floor tool

Wipe and pay close attention to elbow and tube



Dispose of material used to wipe

Place all cleaning material in the bin

Deep cleaning and terminal disinfection



Wear gloves



products being used

Follow instructions of



Ensure full coverage with

attention to touch points. Do not spray directly on to the vacuum.



Wipe the on / off button and

full length of the cable and plug. Do not allow plug to come in contact with liquids.



and floor tool

Wipe and pay close

attention to elbow and tube.



filter into the bin. Wipe vacuum, working

from out to in, top to bottom and from clean to dirty. Allow to fully dry. Refit or replace bag and filter. Reassemble vacuum.



to wipe into the bin

vacuum most effectively Consider upgrading to a HEPA filter

Best practice tips for how to use your

- Make sure the area cleaned is systematically cleaned with overlapping passes to









www.taski.com

*These materials are provided for general information purposes only and do not replace each user's responsibility to assess the operational, legal and other requirements applicable to each facility.